



CRUISE CONTROL SYSTEM Parts Location





Wiring Diagram




- *1: in ECT
- *2: in Combination Meter
- *3: from STOP Fuse
- *4: to Brake Fluid Level Warning Switch

Connector Diagrams



Stop Light Switch




Parking Brake Switch



Neutral Start Switch



Vacuum Switch




Actuator



Vacuum Pump




TOYOTA Diagnostic Communication Link (TDCL)




Speed Sensor (in Combination Meter)



Ignition Switch



Connector "E"



Connector "F"




Engine & ECT ECU

Connector "G"

Connector "H"


Connector "I"



System Description

CONTROL SWITCH operation


Switch	Position
Ignition switch	ON



- The cruise control switch controls MAIN switch, SET/COAST, RESUME/ACCEL and CANCEL function.


1. MAIN SWITCH operation

Switch	Position
Ignition switch	ON
CC MAIN switch	ON




2. SET/COAST SWITCH operation

Switch	Position
Ignition switch	ON
CC MAIN switch	ON
SET/COAST switch	ON



Condition: Continuity ⑨ → ⑩ → ⑦ → Ground (SET/COAST switch ON)


<Actuator Operation> (Current Circuit)



If the SET/COAST switch is released at the moment, the vehicle speed is registered in memory.


3. RESUME/ACCEL SWITCH operation

Switch	Position
Ignition switch	ON
CC MAIN switch	ON
RESUME/ACCEL switch	ON



Condition: Continuity ⑰ → ⑱ → ⑦ → Ground (RESUME/ACCEL switch ON)

<Actuator Operation> (Current Circuit)



If the RESUME/ACCEL switch is released at the moment, the vehicle speed is registered in memory.

4. CANCEL operation

- The Cruise Control is provided with several types of the cancel switch, such as the cruise control switch (CANCEL), the stop light switch, the parking brake switch and the neutral start switch.

(a) Cruise Control Switch (CANCEL)

Switch	Position
CANCEL switch	ON

Condition: Continuity 21 → 22 → 7 → Ground

Then, cancellation signal is send to CC ECU.

(b) Stop Light Switch

Switch	Position
Stop light switch (Brake pedal depressed)	ON

Condition: Continuity 23 → 24 → 25 → Ground

11 → 12
13 → 14

Condition: No continuity 12 → 13

Then, cancellation signal is send to CC ECU.

(c) Parking Brake Switch

Switch	Position
Parking brake switch (Parking brake lever pulled)	ON

Condition: Continuity 26 → 27 → 28 → Ground

Then, cancellation signal is send to CC ECU.

(d) Neutral Start Switch

Switch	Position
Neutral start switch	ON

Condition: Continuity 29 → 30 → 31 → Ground

Then, cancellation signal is send to CC ECU.

Therefore, the operation of the CCS is canceled and the actuator is shut off due to the operation of these switches.

Diagnosis System

Output of Diagnostic Code

READ DIAGNOSTIC CODE


(Type A)

- (a) Turn the ignition switch on
- (b) Turn the control switch to SET/COAST position, and keep it.
- (e) Push the main switch ON.
- (d) Check that the indicator light "CRUISE" in the combination meter.
- (e) Turn the SET/COAST switch off.
- (f) Meet the conditions listed below.
- (g) Read the diagnostic code on the cruise control indicator light.

No.	Conditions	Indication code	Diagnosis
1	Turn the control switch to SET/COAST position.		SET/COAST circuit is normal.
2	Turn the control switch to RES/ACC position.		RES/ACC circuit is normal.
3	Vacuum switch is turned ON.		Vacuum switch circuit is normal.
4	Each cancel switch is turned ON. <ul style="list-style-type: none"> • Control switch (to CANCEL) • Stop light switch • Parking brake switch • Neutral start switch (to N or P range) 		Each cancel switch is normal.
5	Drive approx. 40 km/h (25 mph) or below.		Speed sensor circuit is normal.
6	Drive approx. 40 km/h (25 mph) or over. (w/o ECT)		Speed sensor (in meter) circuit is normal.
7	Drive 40 km/h (25 mph) or over. (w/ ECT)		Speed sensor (in ECT) circuit is normal.

HINT:

- After inspecting No.3, turn the vacuum switch OFF and perform No.4-7.
- Disconnect the vacuum switch connector.
- Idle the engine.
- If there is no indication code, perform diagnosis and inspection. (See page [BE-89](#))
- Indication is stopped when the MAIN switch is repushed.

**(Type B)**

- (a) If while driving with the cruise control on, the system is canceled by a malfunction in either the actuator, speed sensor or control switch circuit, the cruise control indicator light will blink 5 times.
- (b) While stopped, connect terminals 3 and 4 of the TOYOTA Diagnostic Communication Link (TDCL).
HINT: Should the power be cut, the diagnostic code will be erased from the ECU memory.
- (c) Read the diagnostic code on the cruise control indicator light.

	Indication code	Diagnosis
	<p>0.25S 0.25S</p> <p>BE1939</p>	Normal.
11	<p>4S 1.5S 0.5S</p> <p>BE1940</p>	Actuator circuit or Actuator (Control Valve Circuit) is abnormal.
12	<p>1.5S 0.5S</p> <p>BE2711</p>	Actuator circuit or Actuator (Release Valve Circuit) is abnormal.
21	<p>BE1941</p>	Speed sensor (in Meter) circuit is abnormal.
22	<p>BE1942</p>	Speed sensor (in ECT) circuit is abnormal.
23	<p>BE1943</p>	*Vehicle speed has decreased by 16 km/h (10 mph) or more from the set speed.
31	<p>BE1944</p>	RES/ACC switch circuit is abnormal. (Switch signal always turned on.)
33	<p>BE2712</p>	SET/COAST switch signal and RES/ACC switch signal turned on simultaneously.
41	<p>BE4343</p>	ECU malfunction.

*: If the set speed can be maintained when the speed control switch is again set at SET/COAST, there is no malfunction.

HINT:

- Indication codes appear in order from No.11
- If there is no indication code, perform diagnosis and inspection. (See page [BE-89](#))

Troubleshooting


You will find the troubles easier using the table well shown below. In this table, each number shows the priority of causes in troubles. Check each part in order.


Chart No.				E	A	B,C,D	H	J	I	K	K	F,G			
Inspection Item				ECU	Actuator	Main Switch	Control Switch	Stop Light Switch	Neutral Start Switch	Parking Brake Switch	Vacuum Switch	Vacuum Pump	Speed Sensor or Speedometer Cable	Speedometer Cable Function	Others
Diagnosis Code	Type B	Type A													
Problem															
<ul style="list-style-type: none"> "CRUISE" indicator light blinks 5 time. Cruise control system does not set. Cruise control system does not operate. 	11		2	1											
	12		3	1			2								
	21		2										1		
	22		2										1		*2
	23		6	2							5	4	3	1	*3
	31		2			1									
	33		2			1									
	Normal	5	OK	8	7	1	2	3	4	5				6	*4
		NG	2									1			
Setting speed deviated on high or low side.	3	OK	6	5							4	3	2	1	
		NG									1				
Vehicle speed fluctuates when speed control switch turned to SET.			4	3									1	2	
Setting speed does not cancel when brake pedal depressed.	4	OK	3	1			2								
		NG	2				1								
Setting speed does not cancel when parking brake lever pulled.	4	OK	2	1											
		NG	2						1						
Setting speed does not cancel when shifted to "N" range.	4	OK	2	1											
		NG	2					1							
Vehicle speed does not decrease when speed control switch turned to COAST.	1	OK	3	1										2	
		NG	2			1									
Vehicle speed does not accelerate when speed control switch turned to ACC.	2	OK	3	1										2	
		NG	2			1									
Vehicle speed does not return to memorized speed when control switch turned on RESUME.	2	OK	3	1										2	
		NG	2			1									
Setting speed does not cancel when speed control switch turned to CANCEL.	4	OK	2	1											
		NG	2			1									
Speed can be set below about 40 km/h (25 mph).	5	OK	2	1									1		
		NG	2												
Cruise control will not disengage even at about 40 km/h (25 mph).	5	OK	2	1										1	2
		NG	3												
Acceleration response is sluggish when speed control switch turned to "ACCEL" or "RESUME".	3	OK	4	3								2		1	*3
		NG									1	2			

*1 : In the Speedometer or ECT Sensor * 2 : w/ ABS; Rear Speed Sensor or ABS ECU *3 : Vacuum Hose
 *4 : Vacuum Hose & Brake Fluid

Inspection Chart

A INSPECTION OF POWER SOURCE CIRCUIT





B INSPECTION OF SET/COAST SWITCH CIRCUIT

Turn ignition switch off.

CONTROL SWITCH

INSPECT GROUND CONNECTION

Disconnect combination switch connector
Is there continuity between terminal D20 of wire harness side connector and ground?

No

- Open circuit in wire harness between terminal D20 and ground.
- Ground faulty.

Yes

INSPECT CONTROL SWITCH OPERATION

Is control switch operation normal?
(See page BE-110)

No

Replace control switch. Then recheck system.

Yes

Connect combination switch connector.

ECU

Disconnect connector from ECU and inspect connector on wire harness side as follows.

INSPECT SET/COAST CIRCUIT

Is there continuity between terminal B 12 and ground with control switch turned to SET/COAST position?

No

Open circuit in wire harness between terminal B 12 of ECU and terminal D 5 of control switch.

Yes

Is there continuity between terminal B 12 and ground when control switch released?

Yes

Short circuit in wire harness between terminal 6 12 of ECU and terminal D 5 of control switch.

No

ECU faulty.
Replace ECU. Then recheck system.

C INSPECTION OF RES/ACCEL SWITCH CIRCUIT

Turn ignition switch off.

CONTROL SWITCH

INSPECT GROUND CONNECTION
 Disconnect combination switch connector.
 Is there continuity between terminal D20 of wire harness side connector and ground?

No

- Open circuit in wire harness between terminal D20 and ground.
- Ground faulty.

Yes

INSPECT CONTROL SWITCH OPERATION
 Is control switch operation normal?
 (See page BE-111)

No

Replace control switch. Then recheck system.

Yes

Connect combination switch connector.

ECU

Disconnect connector from ECU and inspect connector on wire harness side as follows.

INSPECT RESUME/ACCEL CIRCUIT
 Is there continuity between terminal B 11 and ground with control switch turned to RESUME/ACCEL position?

No

Open circuit in wire harness between terminal B 11 of ECU and terminal D 17 of control switch.

Yes

Is there continuity between terminal B 11 and ground when control switch released?

Yes

Short circuit in wire harness between terminal B 11 of ECU and terminal D 17 of control switch.

No

ECU faulty.
 Replace ECU. Then recheck system.

D INSPECTION OF CANCEL SWITCH CIRCUIT

Turn ignition switch off.

CONTROL SWITCH

INSPECT GROUND CONNECTION

Disconnect combination switch connector
Is there continuity between terminal D20 of wire harness side connector and ground?

No

- Open circuit in wire harness between terminal D20 and ground.
- Ground faulty.

Yes

INSPECT CONTROL SWITCH OPERATION

Is control switch operation normal?
(See page BE-111)

No

Replace control switch. Then recheck system.

Yes

Connect combination switch connector.

ECU

Disconnect connector from ECU and inspect connector on wire harness side as follows.

INSPECT CANCEL CIRCUIT

Is there continuity between terminal B 10 and ground with control switch turned to CANCEL position?

No

Open circuit in wire harness between terminal B 10 of ECU and terminal D 11 of control switch.

Yes

Is there continuity between terminal B 10 and ground when control switch released?

Yes

Short circuit in wire harness between terminal B 10 of ECU and terminal D 11 of control switch.

No

ECU faulty.
Replace ECU. Then recheck system.

E INSPECTION OF ACTUATOR CIRCUIT

Turn ignition switch off.

VACUUM HOSE

Are there cracks or other damage on the vacuum hose?

Yes

Replace vacuum hose. Then recheck system.

No

ACTUATOR

INSPECT CABLE FREEPLAY
Is control cable freeplay less than 10 mm (0.39 in.)?

No

Adjust control cable freeplay.

Yes

INSPECT ACTUATOR OPERATION
Disconnect connector from actuator.
Is actuator operation normal?
(See page BE-112)

No

Replace actuator. Then recheck system.

Yes

Is there continuity between terminal 3 of wire harness side connector and ground?

No

Open circuit in wire harness between terminal 3 of actuator and terminal A8 of ECU.

Yes

STOP LIGHT SWITCH

INSPECT STOP LIGHT SWITCH CIRCUIT
Disconnect connector from stop light switch.
Is there continuity between terminal 4 of wire harness side connector and ground?

Yes

Short circuit in wire harness between terminal 1 of actuator and terminal 4 of stop light switch.

No

Connect the connector to actuator.
Is there continuity between terminal 4 of wire harness side connector and ground?

No

Open circuit in wire harness between terminal 1 of actuator and terminal 4 of stop light switch.

Yes (There is resistance approx. 68 Ω)

INSPECT STOP LIGHT SWITCH OPERATION
Is stop light switch operation normal?
(See page BE-110)


Yes

Replace stop light switch. Then recheck system.

Yes


Connect connector to stop light switch.

CONTINUED ON NEXT PAGE




F INSPECTION OF SPEED SENSOR CIRCUIT (COMBINATION METER SIDE)

SPEEDOMETER CABLE



SPEED SENSOR



CONTINUED ON NEXT PAGE

CONTINUED ON PREVIOUS PAGE

ECU

• Disconnect connector from ECU and inspect connector on wire harness side as follows.

INSPECT SPEED SENSOR CIRCUIT
Is there continuity between terminal A2 of wire harness side connector and terminal 6 7 of ECU?


No

Open circuit in wire harness between terminal A2 of speed sensor and terminal B7 of ECU.


Yes

ECU faulty.
Replace ECU. Then recheck system.

G INSPECTION OF SPEED SENSOR CIRCUIT (ECT SIDE)



H INSPECTION OF STOP LIGHT SWITCH CIRCUIT



INSPECTION OF PARKING BRAKE SWITCH CIRCUIT

Turn ignition switch off.

BRAKE FLUID LEVEL WARNING SWITCH

INSPECT GROUND CONNECTION
Disconnect connector from brake fluid level warning switch. Is there continuity between terminal 2 of wire harness side connector and ground?

No

- Open circuit in wire harness between terminal 2 of brake fluid level warning switch.
- Ground faulty.

Yes

INSPECT BRAKE WARNING SWITCH
Is brake fluid level warning switch operation normal?
(See page BE-43)

No

Replace brake warning switch.

Yes

Connect the connector to brake warning switch.

PARKING BRAKE SWITCH

INSPECT GROUND CONNECTION
Disconnect connector from parking brake switch. Is there continuity between terminal 2 of wire harness side connector and ground?

No

- Open circuit in wire harness between terminal 2 of parking brake switch.
- Ground faulty.

Yes

INSPECT PARKING BRAKE SWITCH OPERATION
Disconnect connector from parking brake switch. Is parking brake switch operation normal?
(See page BE-43)

No

Replace parking brake switch.

Yes

Connect connector to parking brake switch.

ECU

Disconnect connector from ECU and inspect connector on wire harness side as follows.

Ignition switch turned on.

Is there no voltage between terminal 65 and ground with parking brake lever pulled up?

No

Open circuit in wire harness between terminal B 5 of ECU and terminal of parking brake switch.

Yes

Is there battery voltage between terminal B5 and body ground with parking brake released?

No

Short circuit in wire harness between terminal B 5 of ECU and terminal 1 of parking brake switch, terminal 1 of brake fluid level warning switch or parking brake Indicator light.

Yes

ECU faulty.
Replace ECU. Then recheck system.

J INSPECTION OF NEUTRAL START SWITCH CIRCUIT

Turn ignition switch off.

NEUTRAL START SWITCH

INSPECT GROUND CONNECTION

Disconnect connector from neutral start switch. Is there continuity between terminal 3 of wire harness side connector and ground?

No

Open circuit in wire harness between terminal 3 of neutral start switch and ground.

Yes

INSPECT NEUTRAL START SWITCH OPERATION

Is neutral start switch operation normal?
(See page [AT-40](#))

No

Replace neutral switch.

Yes

Connect connector to neutral start switch.

ECU

Disconnect connector from ECU and inspect connector on wire harness side as follows.

INSPECT NEUTRAL START SWITCH CIRCUIT

Is there continuity between terminal B4 and ground when shifted to "N" and "P" range?

No

Open circuit in wire harness between terminal 64 of ECU and terminal 2 of neutral start switch.

Yes

ECU faulty.
Replace ECU. Then recheck system.

K INSPECTION OF VACUUM CIRCUIT

Turn ignition switch off.

VACUUM HOSE

Are there cracks or other damage on the vacuum hose?

Yes → Replace vacuum hose.

No

VACUUM SWITCH

INSPECT VACUUM SWITCH CIRCUIT
Disconnect connector from vacuum switch.
Is there continuity terminal 2 of vacuum switch and ground?

No →

- Open circuit in wire harness between terminal 2 of vacuum switch and ground.
- Ground faulty.

Yes

INSPECT VACUUM SWITCH OPERATION
Is vacuum switch normal? (See page [BE-111](#))

No → Replace vacuum switch.

Yes

VACUUM PUMP

INSPECT GROUND CONNECTION
Disconnect connector from vacuum pump.
Is there continuity between terminal 2 of wire harness side connector and ground?

No →

- Open circuit in wire harness between terminal 2 and ground.
- Ground faulty.

Yes


INSPECT VACUUM PUMP OPERATION
Is vacuum pump operation normal?
(See page [BE-112](#))

No → Replace vacuum pump.


Yes

Connect connector to vacuum switch and pump.


CONTINUED ON NEXT PAGE




L INSPECTION OF ECT SOLENOID CIRCUIT



Wire Harness Side



Connector "A"



Connector "B"

S-10-1 S-12-1


Parts Inspection

1. INSPECT ECU CIRCUIT

Disconnect the connector from the ECU and inspect the connector on wire harness side as shown below.

Connection or Measure item	Check for	Tester Connection	Condition	Specified valve	
Body ground	Continuity	A-7 - Ground	Constant	Continuity	
Vacuum pump		A-9 - Ground	Constant	Continuity * 1	
Vacuum switch		A-10 - Ground	Vacuum	No vacuum	Continuity
				More than 170 f 30 mmHg (6.69 ± 1.18 in.Hg 22.66 ± 4.0 kPa)	No continuity
Stop light switch		B-2 - B-3	Brake pedal position	Depressed	Continuity* 1
				Released	No continuity
Stop light		B-3 - Ground	Constant	Continuity* 1	
Neutral start switch		B-4 - Ground	Shift position	"N" or "P" range	Continuity
				Ex. "N" or "P" range	No continuity
Parking brake switch		B-5 - Ground	Parking brake lever position	Pulled	Continuity
				Released	No continuity
Speed sensor * 3		B-6 - Ground	Vehicle moving slowly	1 pulse per each revolution of propeller shaft	
Speed sensor *4 (in combination meter)		B-7 - Ground	Vehicle moving slowly	1 pulse each 40 cm approx. (15.75 in.)	
MAIN switch*2		B-1 - B-8	Main switch position	Pushed	Continuity
				Released	No continuity
TOYOTA Diagnostic Communication Link		B-9 - Ground	Short terminals between "Tc" and "EI"	Released	No continuity
				Continuity	
CANCEL switch*2		6-10 - Ground	Cruise control switch position	Turned to "CANCEL"	Continuity
				Released	No continuity
RES/ACC switch*2		B-11 -Ground		Turned to "RES/ACC"	Continuity
	Released			No continuity	
SET/COAST switch*2	B-12 - Ground		Turned to "SET/COAST"	Continuity	
			Released	No continuity	
No. 2 solenoid valve * 3	Resistance	A-1 - Ground	Constant	less than 15 0	
Stop light switch and actuator (release valve)		A-3 - A-8	Brake pedal position	Depressed	No continuity
			Released	Approx. 68Ω	
Actuator (control valve)	A-4 - Ground	Constant	Approx. 30 12		
GAUGE fuse and indicator light	Voltage	A-6 - Ground	Ignition switch position	ON	Battery voltage
				LOCK, ACC or ST	No voltage
ECU-IG fuse (Power source)	B-1 - Ground			ON	Battery voltage
				LOCK, ACC or ST	No voltage


*1 : There is resistance in the circuit. *2 : There is on cruise control switch. *3 : There is in ATM. *4 : There is in combination meter



2. INSPECT SWITCHES
(Control Switch/Continuity)

Terminal	B3 (L)	65 (V)	B2 (y)	B15 (R)	B17 (O)	B20 (B)
Switch position						
OFF						
RES/ACC					○	○
MAIN				○		○
SET/COAST		○				○
CANCEL			○			○

If continuity is not as specified, replace the switch.




(Stop Light Switch/ Continuity)

Inspect the switch continuity between terminals.

Terminals	1	2	3	4
Switch position				
Switch pin free (Brake pedal depressed)		○		○
Switch pin pushed in (Brake pedal released)	○		○	

If continuity is not as specified, replace the switch.



(Vacuum Switch/ Operation)

- (a) Check that there is continuity between terminals with no vacuum.
- (b) Check that there is no continuity between terminals with a vacuum of 170 ± 30 mmHg (6.69 ± 1.18 in.Hg, 22.66 ± 4.00 kPa) or above.

If operation is not as specified, replace the switch.

(Parking Brake Switch/ Operation)

See step 2 on page [BE-43](#).

(Neutral Start Switch/ Operation)

See page [AT-40](#).

3. INSPECT SPEED SENSOR


(Combination Meter Side/ Operation)

See step 2 on page [BE-39](#).

(ECT Side)

w/o ABS: See step 6 on page [AT-31](#).

w/ ABS: See Inspection of Rear Speed sensor on page [BR-76](#).



4. INSPECT ACTUATOR


(Resistance)

Measure the resistance value between terminals as follows.

Resistance: 1 – 3 Approx. 68Ω

2 – 3 Approx. 30Ω

If the resistance value is not as specified, replace the actuator.



(Operation)


(a) Connect the positive (+) lead from the battery to terminals 1 and 2, and the negative (-) lead to terminal 3.

(b) Slowly apply vacuum from 0 to 300 mmHg (0 to 11.81 in.Hg, 0 to 40.0 kPa), check that the control cable can be pulled smoothly.

Cable stroke: Approx. 36 mm (1.42 in.)


(c) With the vacuum stabilized, check that the control cable does not return.

HINT: As you apply and hold the vacuum with the vacuum pump, the drawn in diaphragm will in some cases return. This does not indicate a malfunction. Actuator leakage is allowable.



(d) Disconnect terminal 1 or 2 and check that the control cable returns to its original position and the vacuum returns to 0 mmHg (0 in.Hg, 0 kPa).

If operation is not as specified, replace the actuator.



5. INSPECT VACUUM PUMP

(a) Connect a vacuum gauge to the ACT side of the pump.

(b) Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 2.

(c) Check that there is a vacuum of 200 mmHg (7.87 in. Hg, 26.7 kPa) or above.

If operation is not as specified, replace the pump.