

# SYSTEM WIRING DIAGRAMS

## Starting Circuit

1991 Toyota Cressida

