


TOYOTA DIAGNOSTIC COMMUNICATION LINK (TDCL)

The TDCL is provided inside the cabin (located under the left side instrument panel) as a connector exclusively for diagnosis of the TCCS, ECT, ABS and Cruise Control System. The check connector inside the engine compartment is used for engine adjustment.



Connecting the following terminals of the TDCL to terminal E1 selects the diagnosis mode shown.

NOTICE: Never make a mistake with the terminal connection position as this will cause a malfunction.

Terminal	System
T _{E1}	TCCS (Normal mode)
T _{E2} and T _{E1}	TCCS (Test mode)
T _c	ABS and Cruise Control System
T _T	ECT

Refer to the respective system for the inspection method.